



### 232 Series Rocker Switch

Switch shown in the center OFF position

If you want the lamps to illuminate only when you turn the switch to one of the ON positions you need to run 4 small gauge jumper wires as follows: 1A to 2A, 1B to 2B, 4A to 5A and 4B to 5B. The wire gauge isn't important since the lamps don't draw much current.