



Connection Terminals:

- Position One: 8-1
- Position Two: 1-3
- Key Pull Position 1
- Position One is Maintained
- Position Two is Maintained