



*****Note: Terminal connections vary by unit. Follow label on relays for connections.*****

Terminals "M1" & "M2": Motor

Terminal "-": Ground

Terminal "+": +12VDC