

RFR12V-4WP Wiring Diagram

**Wire Connections:

White: Transmitter Button 1Blue: Transmitter Button 4Yellow: Transmitter Button 2

•Grey: Transmitter Button 3

4 Normally Open Outputs**
Outputs close when corresponding button is pressed on transmitter

Note: Isolated Output Contacts-Independent from the power source.

