



The clear protective pouch provides a convenient method to protect the GAMA transmitters from exposure to elements, including submersion in water. The pouch, when properly sealed, will protect the transmitter from dust, dirt and liquids. The pouch has an IP rating of IP67. It is rated for temporary immersion in water.

The pouch is supplied with two open and close tabs at the top, slide the two tabs to the OPEN positions to access the pouch, the two plastic brackets can now be opened to place the transmitter inside the clear pouch. Position the two plastic brackets together and slide the tabs to the CLOSE position.



OPEN




CLOSED

Notice before use:


- Check the bag and accessory for any damage, especially on the clip and the opening of the bag. Do not leave in the sun for long periods of time.
- Sudden temperature changes may cause humidity to form in the bag. If this occurs, open the bag and let it completely dry out.
- If mud, dirt, or sand get in the bag, wash it out completely.
- Do not use in water hotter than 100°F.

1




OPEN

2



**INSERT
TRANSMITTER**

3



CLOSE