238A-B/B Wiring Diagram

Position 1: Maintained



Position 2: Maintained